
DETECT INPUT QUANTITIES
(LW, v)
10
RZ (ROTATIONAL
WHEEL SPEED)
LEFT = f(LW, v)
11
12
RZ (ROTATIONAL
WHEEL SPEED)
RIGHT = f(LW, v)
13
RZ LEFT = RZ RIGHT ± DD
N
CONSTANT TORQUE
AT LONGITUDINAL
CLUTCH
14
SLIP CONTROL
15